INSTRUCTIONS AND WARRANTY

MODEL NO. SPH55-N

SALTON PANEL HEATER

Congratulations on purchasing our Salton panel heater. Each unit is manufactured to ensure safety and reliability. Before using this appliance for the first time, please read the instruction manual carefully and keep it for future reference.

FEATURES OF THE SALTON PANEL HEATER.

IMPORTANT SAFEGUARDS

When using any electrical appliance, basic safety precautions should always be followed including the following:

1. Please read the instructions carefully before using any appliance.
2. Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
3. Incorrect operation and improper use can damage the panel heater and cause injury to the user.
4. The panel heater is intended for household (wall mounted) use only. Commercial use invalids the warranty and the supplier cannot be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
5. The wall panel heaters should under no circumstances be used as free standing heaters.
6. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front of the heater and keep away from the sides and rear.
7. This panel heater is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. An infant or a baby should not be left unattended as prolonged contact with the surface may result in an injury.

9. Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, the manufacturer or a qualified person must replace it in order to avoid an electrical hazard.
10. The heater must not be mounted directly below an electrical wall plug.
11. When first switching on the heater, there may be a slight odour during the first day or two. This is quite normal and is caused by the residual adhesive moisture and does not present any health hazard.
12. Do not use the panel heater if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorised service agent
13. To reduce the risk of electric shock, do not immerse or expose assembly, plug or the power cord to water or any other liquid.
14. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate the heater where it may fall into a bathtub or other water container.
15. Never immerse the unit in water or any other liquid for cleaning purposes.
16. Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the panel heater from the mains. Always unplug the unit when not in use, before cleaning or when adding or removing parts.
17. The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
18. A short cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord.
19. Ensure that the cord is not in a position where it can be pulled on inadvertently.
20. Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.
21. To prevent a possible fire, do not block the space between the heater and the wall that is for air intake or exhaust in any manner.
22. Use of an extension cord with the panel heater is not recommended.
23. This panel heater is not suitable for outdoor use. Do not use this appliance for anything other than its intended use.
24. DO NOT carry the appliance by the power cord.
25. DO NOT COVER the heater under any circumstances.

26. Do not leave the appliance unattended during use. Always unplug the unit when not in use or before cleaning.
27. Always operate the appliance on a smooth, even, stable surface. Do not place the unit on a hot surface.
28. Ensure that the switch is in the “Off” position after each use.
29. The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use, or for repairs carried out by unauthorised personnel.
30. In case of technical problems, switch off the unit and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above mentioned pre-cautions and instructions, could affect the safe operation of this machine.

YOUR ENERGY SAVER SALTON SPH55N wall panel heater is designed as an alternative to conventional bar heaters and other forms of high output heaters that use large amounts of electricity. It operates at relatively low surface temperatures (approximately 75ºC -90ºC depending on the ambient temperature), and uses minimal electricity.

There are numerous advantages to using SALTON SPH55N electric wall panel heaters. They save on floor space, are safer to use around children and pets, operate at the same electricity cost of just four incandescent light bulbs and can be painted to match any décor with PVA or emulsion type paint (do not use oil based paint). SALTON SPH55N wall panel heaters are designed to be left on for long periods of time, giving you comfortable background heat at a low cost. This is similar in concept to a central heating system-yet far less expensive.

ROOM SIZE

Due to variable factors, it is impossible to specify how many wall panel heaters to install in a room. We do recommend the following:

- 1 x 400 Watt wall panel heater per 10-12m² of floor area.

NEW CONVECTION TECHNOLOGY

SALTON SPH55N wall panel heaters provide efficient room heating at a low cost. Using convection technology, heat is generated behind the heater in the space between the panel and the wall, which leads to an efficient up-draught of heat circulated into the room. This principle of convection means that about 90% of the heat comes from the back of the panel, while only 10% is radiated from the front of the panel. Convection heating (whole room heater) is far more effective than radiated heating (free-standing locality heater).

FEATURES & BENEFITS

- Inexpensive to acquire, inexpensive to run.
- Energy saving-save up to 50% or more on your heating costs. Runs on the electricity of just four incandescent light bulbs!
- Efficiently warms a room of approximately 12m².
- Uses efficient convection technology, unlike locality heaters.
- Safer for children and pets-No exposed elements, gas or fans.
- Ultra slim and compact design. Out-of-the way wall mounting.
- Non-flammable. Non-combustible.
- Can be painted
- Eco-friendly
- No drying of the air. No oxygen burnt up.
- Quick and easy to install.

PARTS DIAGRAM

Included in the kit:

1 x 8 mm drill bit, 4 x spacer plugs and 4 x fastening bolts

Unpack your package and find the heater together with the wall mounting accessories pack.

1. Use the holes provided in the lightweight polystyrene packing OR the heater itself as a template to mark the position of the four holes on the wall (ensuring the template is level). For best results the panel heater should be mounted approximately 15cm above floor/skirting board and away from windows and doors.
2. Drill the holes using a 8mm masonry drill
3. Push the spacer plugs into the wall (3).
4. Push the panel heater firmly onto the four spacer plugs.
5. Screw the four fastening bolts into the spacer plugs (5).
6. Place the caps on the fasten bolts. Gently tap the pin into place with a hammer.



OPERATING INSTRUCTIONS

Using the heater for the first time:

1. Check the heater to be sure it is not damaged.
2. After installation put the plug in the socket and switch on the illuminated ON/OFF switch.
3. When you don't need to warm the room, switch the heater off.
4. Unplug the unit from the electrical outlet when not in use



Control Panel Functions			
A	ON/OFF Switch	C	Screw Bolt Cap
B	Control Panel	D	Heater Body

CLEANING AND MAINTENANCE

- This panel heater is for household use only and is not user-serviceable.
- Do not open or change any parts by yourself. Please refer to a qualified electrical service department or return to the supplier if servicing is necessary.
- Always remember to unplug the unit from the electrical outlet when not in use.
- Do not use bleach or other abrasive substance or solvents to clean your appliance as it can be damaging to the finish.
- Do not immerse the panel heater in water or any other liquid, or hold it under a running tap to clean.
- To remove stubborn spots/marks, wipe the surfaces with a cloth slightly dampened in soapy water or mild non-abrasive cleaner.

SERVICING THE APPLIANCE

There are no user serviceable parts in this appliance. If the unit is not operating correctly, please check the following:

- You have followed the instructions correctly
- That the unit has been wired correctly and that the wall socket is switched on.
- That the mains power supply is ON.
- That the plug is firmly in the mains socket.

<u>If the appliance still does not work after checking the above</u>:

- Consult the retailer for possible repair or replacement. If the retailer fails to resolve the problem and you need to return the appliance, make sure that:

- The unit is packed carefully back into its original packaging.
- Proof of purchase is attached.
- A reason is provided for why it is being returned.

If the supply cord is damaged, the manufacturer or an authorised service agent must replace it, in order to avoid any hazard. If service becomes necessary within the warranty period, the appliance should be returned to an approved Tedelex Trading (Pty) Ltd service centre. Servicing outside the warranty period is still available, but will, however, be chargeable.

CHANGING THE PLUG

Should the need arise to change the fitted plug, follow the instructions below.
This unit is designed to operate on 230V-240V current only. Connecting to other power sources may damage the appliance. Connect a plug as follows:
The wires in this mains lead are coloured in accordance with the following code:

Blue = Neutral
Brown = Live



PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE
IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE PRODUCED.

W A R R A N T Y

1. Tedelex Trading (Pty) Limited ("Tedelex") warrants to the original purchaser of this product ("the customer") that this product will be free of defects in quality and workmanship which under normal personal, family or household use and purpose may manifest within a period of 1 (one) year from the date of purchase ("warranty period").
2. Where the customer has purchased a product and it breaks, is defective or does not work properly for the intended purpose, the customer must notify the supplier from whom the customer bought the product ("the supplier") thereof within the warranty period. Any claim in terms of this warranty must be supported by a proof of purchase. If proof of purchase is not available, then repair, and/or service charges may be payable by the customer to the supplier.
3. The faulty product must be taken to the supplier's service centre to exercise the warranty.
4. The supplier will refund, repair or exchange the product in terms of this warranty subject to legislative requirements. This warranty shall be valid only where the customer has not broken the product himself, or used the product for something that it is not supposed to be used for. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, tamper, abuse or any unauthorised modification or repair of the product.
5. This warranty will extend only to the product provided at the date of the purchase and not to any expendables attached or installed by the customer.
6. If the customer requests that the supplier repairs the product and the product breaks or fails to work properly within 3 (three) months of the repair and not as a result of misuse, tampering or modification by or on behalf of the customer, then the supplier may replace the product or pay a refund to the customer.
7. The customer may be responsible for certain costs where products returned are not in the original packaging, or if the packaging is damaged. This will be deducted from any refund paid to the customer.

TEDELEX TRADING (PTY) LTD (JOHANNESBURG)

JOHANNESBURG	TEL NO. (011) 490-9000
CAPE TOWN	TEL NO. (021) 552-5161
DURBAN	TEL NO. (031) 792-6000

www.amap.co.za